# Reverse Osmosis Drinking Water System

Installation, Operation and Service Manual

## **IMPORTANT WARNING - PLEASE READ**

**System Flushing:** This reverse osmosis system contains a preservative solution to prevent microbiological growth and freezing which if ingested may cause irritation of the gastrointestinal tract, colic, diarrhea or other symptoms. Therefore, approximately 5 gallons of water must be drawn from the tap to flush out the preservative solution before using the system. This volume of water represents approximately two days of production. The water flushed should be disposed of to the drain.

**Feed Water Quality:** This reverse osmosis drinking water system is not intended to be used for the treatment of water that is microbiologically unsafe or of unknown quality. If the feed water quality is unsafe or unknown, have a sample of the water tested by a qualified laboratory or agency and implement the necessary measures to ensure a safe water supply.

# TABLE OF CONTENTS

Introduction	1
Product Specifications & Application Guidelines	2
Functional Description	2
Your New Reverse Osmosis System (supplied items checklist)	3
Installation	4
Startup and Operation	9
Maintenance	10
Sanitization Procedures	11
Maintenance Schedule	14
Parts List and Drawing for E75TFC-3SF / E50TFC-3SF	15
Parts List and Drawing for E35TFC-2SF	16
Reverse Osmosis Drinking Water System Flow Diagram (all models)	17
Troubleshooting Guide	18
Warranty Information & Addresses	20

# INTRODUCTION

Congratulations, on the purchase of your new Reverse Osmosis Drinking Water System. Treated with care and regular maintenance, your new system will provide many years of service delivering purified water to the tap.

By now, you have probably already opened the box to survey the contents. Please take a few moments to review this manual before proceeding with the installation and use of the system. Some important items to review are as follows:

- Check all components for any damage caused in shipment. Also, take a quick inventory of all items supplied to ensure none are missing. A checklist in the next section will assist you with identifying these items.
- Ensure that the reverse osmosis system and storage tank will easily fit into the desired location. This reverse osmosis system and tank needs to be removed for regular maintenance, so good accessibility is an important tip to keep in mind.
- Read all warnings contained within this manual.

Although this product is described as a *'Drinking Water System'*, the purified water produced by the reverse osmosis (RO) process can be used for many purposes around the home.

- **Drinking Water** keep container of RO water in the fridge to be able to enjoy the clean, fresh taste. Alternatively, take it directly from the tap.
- **Ice Cubes** use RO water to fill ice cube trays. Ice cubes made from RO water are typically clearer and better tasting than ice made from plain tap water.
- **Automatic Ice Makers** a water line from the RO system can be plumbed to refrigerators with automatic icemakers. Additional accessories required to complete this connection are not included. Please consult the refrigerator's owner's manual on this installation.
- **Kettles and Coffee Makers** plain tap water eventually causes films and scale in these devices that is difficult to clean. RO water is very low in dissolved minerals content, greatly reducing the chance of scale buildup.
- **Cooking** use RO water for boiling pasta, rice or any other recipe that calls for water in the instructions.
- **Washing Fresh Fruit & Vegetables** prevent tap water minerals from being deposited onto food to maintain freshness.
- Family Pets Allow you dog or cat to enjoy the same purified water you do.
- **Irons, Steamers & Humidifiers** prevent mineral buildup in household appliances that use water and eventually build up with scale when using plain tap water.

Now you can relax and enjoy the benefits of great tasting water supplied by your reverse osmosis drinking water system. Remember that good quality water is important to maintaining a healthy lifestyle. You can also feel good about the money you have saved by installing your own drinking water system instead of dealing with the expense and hassle of bottled water delivery.

# **Application Guidelines**

Model Number	E75TFC-3	E50TFC-3	E35TFC-2SF
Membrane Type	TFC	TFC	TFC
Max. Feed Water Salinity	2000 ppm	2000 ppm	2000 ppm
Feed Water Temperature	40-110°F	40-110°F	40-110°F
Feed Water Pressure	50-100 psi	50-100 psi	50-100 psi
Feed Water pH	2.0-11.0	2.0-11.0	2.0-11.0
Feed Water Supply	Chlorinated Unchlorinated	Chlorinated Unchlorinated	Chlorinated Unchlorinated
Feed Water Hydrogen Sulphide	None	None	None
Feed Water Manganese	<0.05 ppm	<0.05 ppm	<0.05 ppm
Feed Water Iron	<0.1 ppm	<0.1 ppm	<0.1 ppm
Feed Water Hardness	<10 gpg	<10 gpg	<10 gpg

# **Specifications**

Model Number	E75TFC-3SF	E50TFC-3SF	E35TFC-2SF
Membrane Production Rate (1)	75 USGPD	50 USGPD	35 USGPD
Rejection (1)	up to 99%	up to 99%	up to 99%
Storage Tank Capacity US Gal	4.0	4.0	4.0

<sup>(1)</sup> Nominal product water ratings are based on the following conditions: Supply TDS of 250 ppm softened tap water, 50 psi (0.36 Mpa), 77°F (25°C), pH 8 and 15% recovery with outlet to atmosphere.

<sup>(2)</sup> Rejection percentages are dependent on the supply conditions and the substance being measured.

Notes:

The performance of a reverse osmosis membrane is highly dependent upon pressure, temperature and TDS. The actual volume of product water and rejection percentage will vary with differences from the test conditions that membrane ratings are based upon.

These drinking water systems are not intended to be used for the treatment of water that is microbiologically unsafe or of unknown quality...

# **Functional Description**

Feed water enters the 5-micron pre-filter (combination 5 micron/carbon filter in 2 sump models), which filters out suspended particles such as dirt or sediment. The filtered water then enters the pre-carbon filter (3 sump models only), which contains granular activated carbon, which removes any chlorine from the water. The two sump models utilize a combination 5-micron/carbon filter to filter fine particles and remove chlorine.

The water then enters the reverse osmosis membrane. The membrane will allow only permeate (product water) to pass through. The brine (waste water) goes to the drain.

Permeate then flows through a hydraulic shut-off valve to the storage tank. When the tank fills and the tank pressure reaches 2/3 of the inlet feed water pressure, the shut-off valve closes, which turns the system off.

When water is drawn from the faucet, permeate flows from the storage tank through the post carbon filter. This filter contains granulated activated carbon, removing any taste and odor that has accumulated while stored in the tank. When the tank empties, the shut-off valve opens, turning the unit on.

# **Supplied Item Checklist**

Out of the box, your new R.O. System should be supplied with the following items. If any items appear to be missing, please contact the distributor who sold the system.



Figure 1 - Supplied items for 2 sump models



Figure 2 - Supplied items for 3 sump models

- 1. Pressure Tank
- 2. Reverse Osmosis System, complete with tubing bundle
- 3. Reverse Osmosis membrane element (in sealed protective bag)
- 4. Filter Sump Wrench
- 5. Length of black tubing
- 6. Drain line saddle assembly
- 7. Feed Water saddle valve assembly
- 8. Mounting screws, two (2)
- 9. Quick connect fitting; 3/8" tube x 1/8" FNPT
- 10. Faucet assembly
- 11. Right angle shut off valve with compression nut

# Installation

All State/Provincial and local government codes regarding installation of these devices must be observed.

## Verify Water Supply is Potable

The water supply must meet provincial/state and/or national standards for potable drinking water. Water samples should be sent to a certified laboratory for analysis.

## Placement of Components

Placement of the various components of the system will vary from installation to installation. The main objective is to place the components so that they are accessible for servicing and ease of installation.

#### Spigot

Proper faucet placement should ensure a no-splash waterfall pattern into the sink. The spigot handle should be positioned to either the left or right as one faces the sink.

#### Storage Tank

The storage tank should be placed so that it can be easily removed from under the sink. **Avoid placing** *the storage tank in out-of-the-way cabinets or dead spaces*. There are two reasons for this: 1) the difficulty of installation increases significantly and 2) when the storage tank is located further away from the faucet, the flow rate diminishes.

#### **Module Assembly**

The module assembly should be hung on a sink cabinet side-wall with the two wood screws provided.

#### **Quick Connect Fittings**

All connections are quick connect fittings except for the compression fitting at the inlet sadle valve, drain saddle valve and storage tank shutoff valve.

#### To Prepare Tubing

- Cut the tube squarely and remove any burrs.
- Mark from the end of the tube the length of insertion. (1/4" O.D. 11/16", 3/8" O.D. 3/4")

#### To Insert Tubing into Fitting

• Insert tube straight into fitting until it bottoms out on interior shoulder and insertion mark is no longer visible.

#### To Release Tubing





Figure 3 - Quick Connect Fitting

## Installation of Feed Water Assembly

The system comes supplied with a saddle-type valve with mounting hardware and is intended to be used on 3/8" to 1/2" copper tubing cold water supply line. NOTE: It is not to be used on flex lines.

- a. Turn off cold water valve under the sink or main valve for the house.
- b. Slide the clamp over the copper tubing and tighten the bottom screw firmly to hold the clamp in position. (See Figure 4)
- c. Slide brass nut, plastic sleeve and tube insert on to the green 1/4" plastic tubing and thread onto valve outlet.
- d. Pierce the copper tubing by turning the needle valve handle (clockwise) until it is firmly seated. The valve is closed in this position.
- e. Turn on main supply valve to pressurize cold water line. Immediately check for any signs of leaks.
- f. When ready to supply water to the system, turn valve handle (counter-clockwise) until fully open.






Figure 4a

Feed Water Assembly

Figure 4b

## Installation of Drain Saddle Assembly

The system comes supplied with a drain saddle and mounting hardware which fits around a standard 1½" O.D.drain pipe (See Figure 5).

- a. The saddle should be installed above the trap and on the vertical or horizontal tailpiece. It should never be placed close to the outlet of a garbage disposal (See Figure 6).
- b. Position saddle assembly on drain pipe to allow adequate space for drilling through pipe. If possible, angle the drain saddle fitting toward spigot location.
- c. Tighten the drain saddle screws evenly and firmly so a good seal is made. Avoid over tightening.
- d. Drill a 5/16" hole in the drain pipe through the drain fitting opening. Support the drain against drilling pressure.
- e. Insert black drain line tubing into compression nut and tighten.

NOTE: Some state or local codes may require that the drain saddle be served by a trap other than the one serving the garbage disposal. Before making a connection as shown in Figure 5, please check with code authorities.




Figure 5 - Drain Saddle Assembly




Figure 6 - Recommended Drain Saddle Connections

## Installation of Ball Valve Assembly

The ball valve and quick connect adapter must be installed on the RO storage tank.

- a. Put 2-3 wraps of Teflon tape on the storage tank threads, and on the 1/4" x 3/8" male connector.
- b. Install the 1/4" x 3/8" male connector onto the ball valve. Tighten the fitting very gently until it is snug. *Be very careful not to over-tighten or the threads may strip.*
- c. Tighten the ball valve assembly onto the RO storage tank. Tighten the fitting very gently until it is snug. *Be very careful not to over-tighten or the threads may strip.*






Figure 7 - Pressure Tank Shutoff Valve

## **Drilling Sink Hole**

The typical 1-1/8" sink hole will accommodate most standard or air gap spigots. Once the location of the spigot has been determined, always check below the point you are about to drill to ensure it is unobstructed and that it isn't over a reinforcing rib.

- a. Center punch the desired location to provide a starting point for your drill.
- b. Drill a 1/8" pilot hole.
- c. Enlarge the pilot hole using a 1-1/8" high speed steel hole saw for air gap faucet.
- d. Enlarge the pilot hole using a 9/16" drill bit for standard faucet.
- e. Remove all burrs and sharp edges.
- f. Immediately clean up the sink area.

NOTE: If an enamel or porcelain sink is encountered, it is very important that the layer of porcelain be removed before following the steps outlined above. This can be accomplished by gently grinding away, using a hobby grinder and silicon carbide wheel, enough area of porcelain down to the metal base to accommodate a 1-1/8" high speed steel hole saw. The hole saw cannot contact surrounding porcelain or chipping can occur. Now the steps outlined above can be followed.

## Installation of Air Gap Faucet

- 1. Place the chrome washer and the rubber washer on the base of the faucet.
- Apply 5-7 wraps of the teflon tape to the bottom of the brass stem. Install 3/8" quick connect faucet adapter provided. Tighten gently until fitting is snug. Be careful not to over-tighten as the threads may strip.
- 3. Attach the 1/4" brine water discharge line to the brine input (small) barb and 1/4" or 3/8" drain line to the brine output (large) barb.
- 4. Mount the faucet and complete assembly.

Note: Before connections are made, tubing should be cut to ensure a neat and orderly installation. The storage tank and spigot tubes should be as short as possible so that the greatest possible flow can be obtained from the spigot.

## Installation of Spigot

See separate installation instructions for spigot

### Installation of Membrane



Figure 8 - Installing membrane without touching

*Important:* Keep the membrane and your hands clean in order to avoid bacterial contamination of the membrane.

- 1. Disconnect the hose on the end of the membrane housing end cap.
- 2. Unscrew the end-cap.
- 3. Hold the membrane upside down, cut the plastic bag at the bottom, and drain off any liquid.
- 4. The bottom tip of the membrane must seat firmly in the protruding female socket inside the membrane housing.
- 5. Without touching the membrane, slide it into the membrane housing and discard the plastic bag. With your thumb or the palm of your hand, push the membrane all the way into the housing. *Important:* Do not use force, and ensure that the membrane is not protruding from the housing.
- 6. Replace the membrane housing end cap and hand tighten.
- 7. Push the tubing back into the quick connect fitting. Ensure the tubing is all the way in.

## **Connecting Components**

- a. Connect the 1/4" green tube from the (90° elbow) 5 micron pre-filter fitting to the fitting on the cold water supply line.
- b. Connect the 3/8" blue tube from the (90° elbow) granular activated carbon post-filter fitting to the quick connect fitting on the threaded pipe on the spigot.
- c. Connect the 3/8" blue tube from the (male tee) granular activated carbon post-filter fitting to the fitting on the storage tank.
- d. Standard Faucet Connect the 1/4" black tube to the drain fitting.

## **Start-Up Procedure**

**WARNING:** To prevent microbiological growth and freezing, this reverse osmosis system contains a preservative solution which, if ingested, may cause irritation of the gastrointestinal tract, colic, diarrhea or other similar symptoms. Therefore, 5 gallons (approximately two full tanks) must be drawn from the spigot to flush out the preservative. This may represent two or three days of running, depending on conditions of the feed water.

The carbon filters require some rinsing to remove carbon fines. The filters will rinse out on their own by allowing the system to produce 2 full tanks of water and discarding the RO product water. The following procedure may be followed if it is desired to rinse the filters immediately before producing an RO product water.



Figure 9 - Disconnect pre-carbon outlet tube from shutoff valve



Figure 10 - Direct flushed water and carbon fines into container

- a. Disconnect the green line from the auto shut off valve that runs from the outlet side of the Pre-Carbon Filter to the Auto Shut Off Valve. Direct tubing into a pail or catch basin.
- b. Turn on the feed water by opening the needle valve on the feed water saddle valve and catch the water in the pail. The water rinsing the filter will appear grayish until the fines are rinsed out. When the water returns to clear, close the needle valve. Re-connect the green tubing back into the Auto Shut Off Valve. The filters are now rinsed.
- c. Turn on feedwater by opening the needle valve. Immediately check for any signs of a leak. Correct any problems if necessary. Turn on storage tank valve.
- d. It will not be uncommon to experience air bubbles or dissolved air in the product water. This will disappear after the unit is in service for a short period of time.
- e. The first two full tanks must be discarded to flush the membrane preservative out of the system as well as flush the carbon fines from the Post Carbon Filter.

## **Maintenance Schedule**

This schedule is designed for the average potable water supply and should be followed to ensure the proper functioning of your drinking water system.

**Pre-Filter** - The pre-filter contains a 5 micron mechanical filter element. Its function is to remove suspended particles from the feed water, thus reducing the possibility of clogging the reverse osmosis membrane. The pre-filter element should be replaced every twelve months or earlier depending on the quality of the feed water.

**Pre-Carbon Filter** -The pre-filter contains a granular activated carbon. Its function is to remove chlorine from the incoming water to prevent any damage to the TFC membrane. The Pre-Carbon filter cartridge should be replaced every 24 months.

**Combination Five Micron Pre-Filter and Carbon Filter** - Removes tiny particles of suspended dirt, sediment and organics, while protecting TFC membrane from chlorine. This filter should be replaced every 12 months.

**Reverse Osmosis Module** - The reverse osmosis module contains a semi-permeable membrane. Its function is to separate water molecules from dissolved impurities in the feed water. This is accomplished by application of hydraulic pressure greater than the osmotic pressure in water containing dissolved solids. The life of the membrane can be determined by measuring the percentage of rejection of total dissolved solids in the water. The membrane should be replaced every 24 to 36 months when its efficiency will decrease.

**Post-Carbon Filter** - The post-filter contains a granular activated carbon. Its function is to remove any taste and odor from the water prior to delivering it to the spigot. The post-filter cartridge should be replaced every 24 months.

## **Changing Filters**



Figure 11 - Using sump wrench to change filter cartridges

**Important:** This RO System contains filters, which must be replaced at regular intervals to maintain proper performance. See Maintenance Schedule for the recommended interval for changing the filters. Local conditions may dictate more frequent cartridge replacement. Use a drip pan to catch any water that may spill when the housings are removed. Use only factory approved filters.

- 1. Close the saddle valve by turning fully clockwise and open the faucet by lifting the handle. Allow storage tank to empty.
- 2. Loosen and remove the appropriate filter housing(s). Discard the cartridge(s).
- 3. Wash the inside of the housings using a mild detergent and a soft cloth. Do not use abrasive cleaners or pads. Thoroughly rinse all soap from the housing before re-assembly.

## Sanitization Procedures for your Reverse Osmosis System

Sanitization is a simple but important part of a regular maintenance routine required to keep your Reverse Osmosis Drinking Water System operating properly.

Recording the dates of all maintenance and sanitization done on the unit is a good idea as well as marking on your calendar future service interval dates. Your water system installer may have a maintenance service program to deal with cartridge replacement and system sanitization by setting up regular scheduled service calls.

#### Sanitization maintenance of the Reverse Osmosis Drinking Water System should be performed:

- Upon installation
- At least every 6 12 months as part of a regular maintenance routine.
- Whenever the pre-filter and post-filter cartridges are replaced as part of a regular maintenance routine.
- Whenever the reverse osmosis membrane is replaced.
- After the system requires any servicing or routine maintenance by your local water treatment specialist.
- After long periods of time when system is not used (approximately 30 days or more)
- Whenever evidence of harmful bacteriological contamination of the system has been discovered. In this case contact your local water treatment specialist to disinfect your reverse osmosis system, and identify and eliminate the source of contamination.

IMPORTANT: This Reverse Osmosis Drinking Water System should not be used on any water supply sources that are microbiologically unsafe or of unknown quality without adequate disinfection before and/or after the system.

#### Materials required for Sanitization of the Reverse Osmosis Drinking Water System:

- Mild soap solution to clean various components. Soap used should be as basic as possible and not contain any fragrances or additives.
- Soft brush to assist cleaning various components. (DO NOT USE SCOURING PADS OR ANY OTHER TYPE OF INSTRUMENT THAT COULD POTENTIALLY SCRATCH THE SURFACES OF THE UNIT.)
- Measuring spoon or device.
- Household bleach, typically containing 5.25% of chlorine.
- One (1) Gallon of potable water to mix up a disinfectant solution. (DO NOT USE WATER THAT IS NOT CONSIDERED POTABLE OR IS OF A QUESTIONABLE NATURE TO MIX UP THE DISINFECTANT SOLUTION)
- Drip pan or catch basin to collect any solution or water spilled along with paper towels to cleanup any spills.
- Silicone Based Lubricant to apply to O-Rings. (DO NOT USE PETROLEUM BASED LUBRICANTS)

#### Available Item # 13691 - 60 gram vial (Certified ANSI/NSF 61, FDA Registration No. 21 CFR 715.300)

#### Other important requirements of note:

- Before beginning installation and/or sanitization procedure, make sure that all tools used are disinfected.
- Thoroughly wash hands with soap before beginning installation and/or sanitization procedure. If your hands come into contact with any unsanitary surface while performing this procedure or the installation, hands should be rewashed with soap.
- Any surfaces used to work with to set various components on to dry, should be cleaned and disinfected.
- Any replacement cartridges, membranes and cleaned components should be handled as little as possible.
- A new pair of latex or surgical type gloves may be used to perform any sanitization procedure, but also be aware that if the gloves surface comes into contact with any unsanitary surface while performing this procedure or the installation, the gloves should also be re-disinfected or replaced.

## **Sanitization Steps**

**STEP 1:** TURN OFF WATER SUPPLY - CLOSE INLET SUPPLY NEEDLE VALVE ALL THE WAY

**STEP 2:** DEPRESSURIZE SYSTEM - OPEN FAUCET SUPPLY UNTIL ALL WATER IS EMPTIED

Use a clean drip pan or basin to continue to catch any spilled water remaining in the housings as you remove the membrane and cartridges.

**STEP 3:** DISCONNECT THE FEED TUBE FROM THE MEMBRANE HOUSING MODULE. UNSCREW THE MEMBRANE HOUSING MODULE END CAP AND REMOVE THE MEMBRANE ELEMENT. PUT THE MEMBRANE ELEMENT ASIDE ON A CLEAN DISINFECTED SURFACE. (Unless the membrane element is being replaced at this time, then discard the old membrane.)

**STEP 4:** OPEN THE FILTER SUMPS WITH THE SUMP WRENCH SUPPLIED AND REMOVE THE CARTRIDGES.

**STEP 5:** CLEAN THE FILTER SUMPS WITH SOAP AND CLEAN WATER. USE A CLOTH OR SOFT BRUSH AS REQUIRED. CLEAN THE INSIDE OF THE MEMBRANE HOUSING AS WELL.

(You may need to pay close attention to the O-Ring seals and re-grease them afterwards with silicone lubricant)

**STEP 6:** REINSTALL THE FILTER SUMPS (EXCEPT THE 1ST PRE-FILTER SUMP) AND THE MEMBRANE CAP AND RECONNECT THE INLET TUBING TO THE MEMBRANE HOUSING CAP.

**STEP 7:** MIX UP A DISINFECTANT SOLUTION OF 1 TEASPOON OF 5.25% BLEACH IN 1 GALLON OF WATER.



Figure 12



Figure 13



Figure 14

**STEP 8:** POUR THE MIXED DISINFECTANT SOLUTION INTO THE 1ST PRE-FILTER SUMP AND RE-INSTALL.

**STEP 9:** OPEN THE INLET SADDLE VALVE AND OPEN THE FAUCET. WHEN WATER BEGINS RUNNING FROM THE FAUCET AGAIN, CLOSE THE FAUCET AND ALLOW THE PRESSURE TANK TO FILL FOR 5 - 10 MINUTES. WHEN THE PRESSURE TANK FEELS LIKE IT HAS FILLED, CLOSE THE INLET SUPPLY NEEDLE VALVE.

**STEP 10:** ALLOW THE SYSTEM TO SIT WITH THE DILUTED SANITIZING SOLUTION FOR APPROXIMATELY 20 MINUTES.

**STEP 11:** OPEN THE FAUCET AND PURGE THE TANK AND SYSTEM OF THE SANITIZING SOLUTION.

**STEP 12:** REINSTALL THE MEMBRANE AND REPLACE THE CARTRIDGES. PURGE THE PRE-CARBON CARTRIDGE OF FINES (as per installation instructions). OPEN THE INLET SUPPLY NEEDLE VALVE AND ALLOW SYSTEM TO FILL.

OPEN THE FAUCET AND DISCARD THE FIRST TANK FULL OF WATER. (IF A NEW MEMBRANE ELEMENT IS INSTALLED A THIS TIME, DISCARD THE FIRST TWO TANKS FULL OF WATER).



Figure 15



Figure 16

# Reverse Osmosis Drinking Water System Maintenance Record

## Installation Date: \_\_\_\_\_


Use this chart to record the dates of any cartridge changes. It is meant to assist you on keeping track of this maintenance.

#15500243 WTB10	#26091 WSW-05B	#26081 WCB-10	#92008,92035,92022 TFC RO Membrane	Sanitization Procedure
Carbon/Sediment Dual Cartridge	5 micron Sediment Cartridge	Carbon Cartridge	35, 50 or 75 USGPD Rated Membrane	(refer to instructions)
2 sump models only	3 sump models	3 sump models (x2)	refer to model	all models
Every 12 months	Every 12 months	Every 24 months	24-36 months*	Every 6-12 months

\* The replacement frequency of the R.O. membrane is somewhat dependent on the feed water quality. If the product water quality has decreased or the production of water had dropped off, the membrane requires replacement.

## Parts List and Drawing - Models E(50 & 75) TFC-3SF

Note: There may be some parts listed, which are not included with this model.



Drawing No.


**Description** 

Item No.

1 Tubing, 3/8" OD, poly, blue	87600
3 Tubing, 1/4" OD, poly, green	115204
4 Tubing, 1/4" OD, poly, black	87606
5 Valve, 3/8", Shut Off	80704
6 Adapter, faucet, 3/8", QC	92407
9 Tank, storage, RO, 3800, white, c/w shut off	92313
10 Valve, saddle, SV-6	92276
11 Elbow, male, 1/4" x 1/8" npt	92406
12 Elbow, male, 1/4" x 1/4" npt	92405
13 Elbow, male, 3/8" x 1/4" npt	92404
14 Swivel tee, male, 3/8" x 1/4" npt	92403
16 Membrane, RO	
	92035
75 GPD, TFC	92022
17 Housing, cartridge, white/black	92026
18 Cartridge, pre-filter, 5 micron	26091
19 Cartridge, carbon	26081
20 Saddle, drain, set, RO, 3/8"	92160
21 Clip, pipe, 2", set	92162
22 Faucet, standard	87511
23 Vessel, membrane	92211
24 Valve, shut-off, auto	92223
25 Control, flow	
	92263
	92293
26 Valve, check, product water	92258
27 Bracket, RO, 3 housing	92279
28 Bracket, Shut Off, Auto	92224
32 Tubing, 3/8" OD, poly, natural	115207
33 Elbow, 1/4" QC x 3/8" Stem	92428

# Parts List and Drawing - Model E35TFC-2SF


Note: There may be some parts listed, which are not included with this model.



#### Drawing No.

awing No.	Description	Item No.
1	Tubing, 3/8" OD, poly, blue	87600
2	Tubing, 1/4" OD, poly, black	115205
3	Tubing, 1/4" OD, poly, green	115204
5	Valve, 3/8", Shut Off	80704
6	Adapter, faucet, 3/8", QC	92407
9	Tank, storage, RO, 3800, white, c/w shut off	92313
10	Valve, saddle, SV-6	92276
11	Elbow, male, 1/4" x 1/8" npt	92406
12	Elbow, male, 1/4" x 1/4" npt	92405
13	Elbow, male, 3/8" x 1/4" npt	92404
14	Swivel tee, male, 3/8" x 1/4" npt	92403
15	Connector, union, 3/8" - 1/4"	92402
16	Membrane, RO, 35 GPD, TFC	92008
17	Housing, cartridge, white/black	92026
18b	Cartridge, carbon/SED,WTB10	15500243
19	Cartridge, carbon	26081
20	Saddle, drain, 1/4"	92159
21	Clip, pipe, 2", set	92162
22a	Faucet, standard	87511
23	Vessel, membrane	92211
24	Valve, shut-off, auto	92223
25	Control, flow, 150 ml, RO 35 GPD	92260
26	Valve, check, product water	92258
27	Bracket, Shut Off, Auto	92224
31	Bracket, RO, 2 housing	92265
32	Tubing, 3/8" OD, poly, natural	115207

# Reverse Osmosis Drinking Water System Flow Diagram (all models)



# **Trouble Shooting Guide**

Probable Cause	Solutions
No water or not enough water	
1. Feed water shut off	Turn on feed water
2. Storage tank valve shut off	Open tank valve
3. Plugged or crimped lines	Remove blockage or crimp in lines
4. Pre-filter cartridge clogged	Replace pre-filter cartridge
5. Low feed water pressure	Feed water pressure at membrane must be at least 50 psi
Low flow rate from faucet	
1. Low air pressure in storage tank	Increase air pressure to 7 psi in storage tank with product water drained
2. Storage tank valve partially closed	Open tank valve completely
High product water TDS	
1. Insufficiently flushed filters	5 gallons (approx. 2 full tanks) must be drawn from spigot to sufficiently flush filters
2. Increase in feed water TDS	Contact dealer for revised product water TDS
3. Membrane life expired	Replace membrane
Bad tasting water	
1. Taste from glass or plastic containers	Contact dealer for explanation
2. Post carbon filter cartridge exhausted	Replace post carbon filter cartridge
3. Storage tank and/or system contaminated	Contact dealer for assistance
4. Membrane life expired	Replace membrane
Cloudy water	
1. Dissolved air in feed water gets concentrated in product water.	Condition usually clears up eventually as feed water changes. Letting water stand will allow dissolved air to dissipate.
Cloudy ice cubes	
1. See cloudy water	See cloudy water
<ol> <li>Certain ice cube shapes trap dissolved air more than others. The larger, more squared off cubes are clearest, smaller rounded surface ice cubes are cloudier</li> </ol>	Change ice cube mold shape, make cubes manually if using automatic ice cube maker, let stand to release dissolved air before freezing

# Warranty

#### Five Year Limited Warranty:

Your new drinking system is warranted to the original consumer purchaser, when located at the original installation site, to be free from defects in material and workmanship under normal use within the application guidelines specified by the manufacturer and subject to regular maintenance as described in the Owner's Manual. The entire system (excluding the reverse osmosis membrane and the disposable filter cartridges, which are not warranted) is warranted for a period of five years from date of purchase and we will repair or replace any part which we find to be defective in operation because of faulty materials or workmanship.

#### Two Year Pro-Rated Warranty

The reverse osmosis membrane is warranted to be free from defects in material and workmanship for one year from date of purchase, when operated within the application guidelines. If found to be defective, we will replace said membrane free of charge. Should the membrane fail within the second year of service, you may purchase a new replacement module at a price equal to 3% of the then current retail price, times the number of months or portion thereof of service delivered by the original membrane. The membrane is not warranted beyond the two year period.

#### **Condition of Warranty**

Damage to any part of this reverse osmosis unit because of misuse, misapplication, neglect, alteration, accident, physical damage, fouling and/or scaling of membrane by dirt, sediment, minerals or bacteria attack, installation or operation contrary to our printed instructions or damage caused by hot water, freezing, flood, fire or Act of God, is not covered by this warranty. In all such cases, regular parts and service charges will apply. This warranty is void if unit is altered or repaired by anyone other than an authorized service representative.

All shipping charges on units or parts submitted to our facility for repair or replacement must be borne by the registered purchaser, as well as any costs or labor charges resulting from the removal or installation of the repaired or replaced part.

The drinking water system must be installed on a potable water supply and is not warranted to render an unsafe water supply potable.

This warranty is in lieu of all other warranties, expressed or implied, including warranties of fitness for a particular purpose. Because of fluctuating water quality and varying usage rate, we assume no liability for the determination of the proper equipment necessary to meet your requirements and we do not authorize others to assume for us such or any other obligations on the sale of this drinking water system.

We assume no warranty liability in connection with this reverse osmosis unit other than as specified herein. This is the exclusive remedy and liability for incidental and consequential damages or injury to person or property, attributable to the manufacturer's negligence or fault, under any and all warranties are excluded to the extent exclusion is permitted by law.